




No.	PARTSNAME	No.	PARTSNAME	No.	PARTSNAME
10	Handleshaftretainer	100	Lever hub cover	195	Rod clamp
14	Handle shaft cover	101	Low speed pinion gear	198	Spool spring washer
54	Drag washer	102	Alarm sound slice	199	Spool washer
55	Fixed screw	103	Friction washer	202	Handle knob screw
73	Alarm lever	104	"E" washer	210	Reel foot screws
74	Drag tension knob	105	Drag control lever arm	211	Stopping bracket screw
75	Drag control lever cap	106	Alarm lever screw	212	Side plate screws
76	Drag control lever	107	Harness lugs screw	214	Spool drag screw
77	Ball bearing	108	Limited piecescrew	220	Stopping bracketspring
78	Left side plate	109	Cover screw	222	Spool shaft spring
79	Frame	111	Alarm spring	223	Drag control lever washer(B)
80	Right side cover	113	Limited button spring	226	Sound slice
81	Front plate	114	Sound nail spring	227	Drag control lever thrust ring
82	Spool	115	Alarm lever base	256	Handle knob
83	Pressure plate	142	Reel foot	319	Dial washer
84	Holder nut	159	Drive shield	477	Handle arm
85	Drive shaft cover	163	Drive shaft washer	478	Drive shaft
86	Pre-program screw	164	Washer	479	Drive gear-high speed
87	Pre-program key	165	Fixed nuts	480	Drive shaft screw
90	Alarm lever cross pin support	168	Sound nail	481	Handle bolt
91	Alarm hammer	172	Limited spring	483	Stopping slice
93	Eccentric	177	Anti reverse dog	581	T handle nail
94	Limited bushing	178	Sound plate screw	602	Handleshaft fixed screw
95	Limited nail	182	Spool nail	720	Anti-reverse ratchet
97	Limited pin	186	Thrust washer	723	Wrench
98	Harness lugs	187	"E" washer	903	Limited button
99	Limited piece	191	Stopping bracket		