




No.	PARTSNAME	No.	PARTSNAME	No.	PARTSNAME
10	Handle shaft retainer	175	Alarm hammer	223	Drag control lever washer(B)
95	Limited nail	176	Alarm crossspin support	224	Pre-program plate washer
104	"E" washer	177	Anti reverse dog	225	Spacer
112	Limited spring	178	Sound plate screw	226	Sound silce
114	Soundnailspring	182	Spool nail	227	Dragcontrol lever thrust ring
139	Spool	183	Harness lugs	228	Alarm limited coat
140	Frame	186	Thrust washer	229	Alarm lever base
141	Fixed screw	187	"E" washer	232	Drag control lever
142	Reel foot	188	Eccentric	234	Drag washer
144	High speed pinion gear	191	Stopping bracket	236	Alarmsupport
146	Alarm lever cap	195	Rod clamp	239	Drag control lever cap
147	Drag control lever	198	Spool spring washer	255	Handle knob
148	Alarm lever slice	199	Spool washer	313	Drive shaft spring
150	Right side cover	200	Alarm sound slice	319	Dial washer
151	Left side plate	201	Friction washer	382	Ball bearing
154	Handle shaft cover	202	Handle knob screw	477	Handle arm
155	Drag tension knob	203	Alarm washer	480	Drive shaft screw
159	Drive shield	204	Side plate screws	481	Handle bolt
160	Leverhub cover	205	Haness lugs screw	482	Drive shaft
161	Drive shaft cover	207	Shaft screw	483	Stopping slice
163	Drive shaft washer	208	Crosspinfixedscrew	484	Drive gear-high speed
164	Ratchet washer	209	Alarm lever screw	527	T handlenail
165	Fixed nuts	210	Reel foot screws	529	Handle shaft coat washer
166	Cover screw	211	Stopping bracket screw	544	Pressure plate
167	Pre-program screw	212	Side plate screws	717	Handle shaft fixed screw
168	Soundnail	214	Spool drag screw	720	Anti-reverse ratchet
171	Crosspinsupport	218	Alarm lever spring	723	Wrench
172	Pre-program key	219	Alarm spring		
173	Limited bushing	220	Dog spring		
174	Alarm lever crossspin support	222	Spool shaft spring		