




No.	PARTSNAME	No.	PARTSNAME	No.	PARTSNAME
10	Handle shaft retainer	178	Sound plate screw	223	Drag control lever washer(B)
95	Limited nail	182	Spool nail	224	Pre-program plate washer
104	"E" washer	183	Harness lugs	225	Spacer
112	Limited spring	186	Thrust washer	226	Sound silce
114	Soundnailspring	187	"E" washer	227	Dragcontrol lever thrust ring
146	Alarm lever cap	188	Eccentric	228	Alarm limited coat
147	Drag control lever	189	Reel foot	229	Alarm lever base
148	Alarm lever slice	191	Stopping bracket	232	Drag control lever
149	Spool	195	Rod clamp	234	Drag washer
150	Right side cover	197	High speed pinion gear	236	Alarmsupport
151	Left side plate	198	Spool spring washer	239	Drag control lever cap
152	Frame	199	Spool washer	255	Handle knob
154	Handle shaft cover	200	Alarm sound slice	313	Drive shaft spring
155	Drag tension knob	201	Friction washer	319	Dial washer
159	Drive shield	202	Handle knob screw	382	Ball bearing
160	Leverhub cover	203	Alarm washer	477	Handle arm
161	Drive shaft cover	204	Side plate screws	480	Drive shaft screw
163	Drive shaft washer	205	Haness lugs screw	481	Handle bolt
164	Ratchet washer	207	Shaft screw	482	Drive shaft
165	Fixed nuts	208	Crosspirfixedscrew	483	Stopping slice
166	Cover screw	209	Alarm lever screw	484	Drive gear-high speed
167	Pre-program screw	210	Reel foot screws	527	T handlenail
168	Soundnail	211	Stopping bracket screw	529	Handle shaft coat washer
171	Crosspinsupport	212	Side plate screws	544	Pressure plate
172	Pre-program key	213	Fixed screw	552	Fixed nuts
173	Limited bushing	214	Spool drag screw	717	Handle shaft fixed screw
174	Alarm lever crosspin support	218	Alarm lever spring	720	Anti-reverse ratchet
175	Alarm hammer	219	Alarm spring	723	Wrench
176	Alarm crosspin support	220	Dog spring		
177	Anti reverse dog	222	Spool shaft spring		