




No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME
17	Washer 2	584	Push nail	863	High speed pinion gear
39	Button screw	593	Push slice	864	Low speed pinion gear
66	Spool spring washer	594	Stopping slice	865	Drive gear-high speed
178	Set plate nail	598	Handle bolt washer	866	Drive gear-low speed
185	"E" washer	601	Washer 3	867	Drive shaft
195	Rod clamp	602	Handle knob screw 2	868	Push button shaft
207	Push slice screw	603	Push spring	869	Slide pole
211	Set plate screws	604	Spool shaft spring	870	Spool cannulation
214	Alert ratchet screws	630	"O" ring	871	Variable-speed pin
215	Cover screw	631	Wrench	872	Handle bolt
379	Ball bearing (S117)	657	Alarm sound gear	873	Strike alert lever
381	Ball bearing (S606)	665	Big ring	878	Anti-reverse ratchet
384	Ball bearing (S6700)	666	Small ring	884	"C" washer
390	Ball bearing (S696)	668	Side plate screws 1	885	Handle washer
398	Pre-program plate	669	Side plate screws 2	886	Reel foot screws
406	Set plate	670	Close cover screws	887	Drive shaft spring
416	"E" washer	679	Washer 1	888	Shaft insert spring
417	Drag knob cover	681	Alert ratchet	889	Drive shaft coat washer
419	Pre-program key pin	683	Limited bushing	890	Cover
421	Bearing cover	685	Handle knob	891	Variable-speed washer
423	Drag plate washer	697	Handle arm	892	Drag plate
424	Spool shaft screw	703	Spool ring	896	Spool
426	Screw for bearing cover	831	Drive shaft coat	897	Drag plate undersleeve
429	Bearing ring	833	Spring cover for silence	898	Spool spring washer
430	Drag control lever washer	835	Rear drag plate	899	Friction spring
431	"O" ring	852	Drag tension knob	901	Pre-program key
503	Fixed screws	855	Right plate	909	Close cover
506	Reel foot	856	Frame	910	Anti-reverse dog
546	Drive shaft washer	857	Drag control lever		
574	Button basement	859	Button lever knob		
581	T handle nail	862	Spool shaft		