




No.	PARTSNAME	No.	PARTSNAME	No.	PARTSNAME
10	Handleshaftretainer	99	Limitedpiece	187	"E" washer
14	Handle shaft cover	100	Lever hub cover	191	Stopping bracket
54	Drag washer	101	Pinion gear high speed	195	Rod clamp
55	Fixed screw	102	Alarm sound slice	198	Spool spring washer
56	Push button shaft	103	Spool washer	199	Spool washer
57	Drive shaft	104	"E" washer	202	Handle knob screw
67	Push slice	105	Drag control lever	206	Retainer screw
68	Alarm lever knob	106	Alarm lever screw	210	Reel foot screws
73	Alarmlever	107	Haness lugs screw	211	Stopping bracket screw
74	Drag tension knob	108	Limitedpiecescrew	212	Side plate screws
75	Drag control lever cap	109	Cover screw	214	Spool drag screw
76	Drag lever	110	Pushbuttonspring	220	Stoppingbracketspring
77	Ball bearing	111	Alarm spring	221	Drive shaft spring
78	Left side plate	112	Limited spring	222	Spool shaft spring
79	Frame	113	Alarm lever spring	223	Drag control lever washer(B)
80	Right side cover	114	Soundnailspring	226	Sound silce
81	Front plate	115	Alarmlever base	227	Dragcontrol lever thrust ring
82	Spool	142	Reel foot	230	Various speed washer
83	Pressure plate	153	Button base	231	Gear washer
84	Holder nut	158	Handle arm	256	Handle knob
85	Drive shaft cover	159	Drive shield	258	Drive shaft screw
86	Pre-program screw	162	Slide coat	312	Shaft insert spring
87	Pre-program key	163	Drive shaft washer	319	Dial washer
88	Drive gear-high speed	164	Washer	581	T handle nail
89	Drive gear-low speed	165	Fixed nuts	602	Handle shaft screw
94	Limited bushing	168	Soundnail	720	Anti-reverse ratchet
95	Limited nail	169	Fixednail	723	Wrench
90	Alarmlevercrosspinsupport	177	Anti reverse dog	902	Pinion gear low speed
91	Alarm hammer	178	Sound plate screw	903	Limited button
92	Handle bolt	180	Slide knob		
93	Eccentric	182	Spool nail		
96	Gear shaft pin	184	Stopping slice		
97	Limited pin	185	"E" washer		
98	Harness lugs	186	Thrust washer		