



No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME
17	Washer 2	574	Button basement	827	Spool shaft
39	Button screw	581	T handle nail	831	Drive shaft coat
66	Spool spring washer	584	Push nail	833	Spring cover for silence
178	Set plate nail	593	Push slice	849	Right plate
185	"E" washer	594	Stopping slice	850	Frame
195	Rod clamp	598	Handle bolt washer	851	Drag control lever
207	Push slice screw	601	Washer 3	852	Drag tension knob
211	Set plate screws	602	Handle knob screw 2	859	Button lever knob
214	Alert ratchet screws	603	Push spring	863	High speed pinion gear
379	Ball bearing (S117)	604	Spool shaft spring	864	Low speed pinion gear
381	Ball bearing (S606)	630	"O" ring	865	Drive gear-high speed
384	Ball bearing (S6700)	631	Wrench	866	Drive gear-low speed
390	Ball bearing (S696)	656	Spool spring washer	867	Drive shaft
398	Pre-program plate	657	Alarm sound gear	868	Push button shaft
406	Set plate	665	Big ring	869	Slide pole
415	Strike alert lever	666	Small ring	871	Variable-speed pin
416	"E" washer	668	Side plate screws 1	872	Handle bolt
417	Drag knob cover	669	Side plate screws 2	878	Anti-reverse ratchet
419	Pre-program key pin	670	Close cover screws	884	"C" washer
421	Bearing cover	679	Washer 1	885	Handle washer
423	Drag plate washer	681	Alert ratchet	887	Drive shaft spring
424	Spool shaft screw	683	Limited bushing	888	Shaft insert spring
425	Cover screw	685	Handle knob	889	Drive shaft coat washer
426	Screw for bearing cover	697	Handle arm	891	Variable-speed washer
429	Bearing ring	698	Spool ring	897	Drag plate undersleeve
430	Drag control lever washer	818	Spool	899	Friction spring
431	"O" ring	820	Spool cannulation	901	Pre-program key
452	Reel foot screws	822	Rear drag plate	910	Anti-reverse dog
503	Fixed screws	824	Close cover		
500	Reel foot	825	Cover		
546	Drive shaft washer	826	Drag plate		